


# Maytag A22CA 08 - POWER UNIT & CENTER ASSEMBLY



Maytag Commercial Maytag A22CA Washer Parts Parts Diagram 08 - POWER UNIT & CENTER ASSEMBLY  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y0A4298	<a href="#">6-0A57420</a>		Seal- Agitator
002	Y014792	<a href="#">6-0A57420</a>		Seal- Agitator
003	<a href="#">Y014827</a>			Washer-Center Shaft
004	<a href="#">Y014839</a>			Collar-Drive Shaft
005	<a href="#">Y015149</a>			Brass Washer-Agitator Seal
006	<a href="#">Y015494</a>			Stop Ring-Agitator Shaft
007	<a href="#">Y015629</a>			Bolt, Grinding Chamber
008	NLA		Not Available	DOWEL PIN
009	<a href="#">Y015666</a>			Washer, Retaining -
010	<a href="#">Y015667</a>			Retaining Ring
011	<a href="#">Y015902</a>			Spring For Agitator
012	038313	<a href="#">22038313</a>		Wrench, Spanner
013	<a href="#">Y038555</a>			Tool-Install Center Shaft
014	<a href="#">Y054867</a>			Washer, Lock
015	<a href="#">Y056016</a>			Center Seal Grease
016	Y056080	<a href="#">6-0560800</a>		Oil

017	200730	<a href="#">22002124</a>		Shaft- Agi
018	NLA		Not Available	GEAR CASE COVER ASSEMBLY
019	200824	<a href="#">6-2040130</a>		Tub Bearin
020	NLA		Not Available	PITMAN WITH WRIST PIN
021	201537	<a href="#">6-2095720</a>		Mounting S
022	202521	<a href="#">6-2095720</a>		Mounting S
024	NLA		Not Available	GEAR HOUSING W/STUDS & TUBE
025	203723	<a href="#">W10172457</a>		Transmison
026	204012	<a href="#">6-2095720</a>		Mounting S
027	204013	<a href="#">6-2040130</a>		Tub Bearin
029	<a href="#">204967</a>			Gear Kit-Power Fin Agitator
030	<a href="#">210054</a>			Pinion
031	NLA		Not Available	RETAINING RING
032	<a href="#">210183</a>			Groove Pin
033	<a href="#">210286</a>			Seal
034	<a href="#">210315</a>			Pinion
035	210632	<a href="#">22210632</a>		Gasket
036	NLA		Not Available	SEGMENT
037	<a href="#">210690</a>			Seal, Rubber
038	NLA		Not Available	BEARING
039	211028	<a href="#">22001586</a>		Deflector, Water
040	211047	<a href="#">6-2110472</a>		Nut- Clamp
041	<a href="#">211089</a>			Lug, Stop Pulley
042	211090	<a href="#">22003555</a>		Washer, Stop Lug
043	<a href="#">211100</a>			Washer, Outer Tub
044	<a href="#">211130</a>			Bearing Liner, Tub Bearing
045	<a href="#">211210</a>			Washer, Clamping Nut
046	211375	<a href="#">681582</a>		Screw
047	211483	<a href="#">6-2114830</a>		Washer- SP
048	<a href="#">211484</a>			Washer, Lug
049	<a href="#">211486</a>			Screw, 3/8-16 X 1/2 Inch
050	NLA		Not Available	GROOV-PIN
051	211618	<a href="#">22001423</a>		Set Screw, Mounting Stem
052	NLA		Not Available	SPRING FOR TUB SEAL
054	<a href="#">213044</a>			Shaft, Center
055	NLA		Not Available	WASHER FOR GEARS
056	NLA		Not Available	COUNTERWEIGHT
057	<a href="#">Y052740</a>	<a href="#">62739</a>		Nut, Lock
058	NLA		Not Available	CAP SCREW (3/8-16 X 1)