


# Maytag DE18CA 02 - FRONT VIEW (SERIES 03)



Maytag Commercial Maytag DE18CA Dryer Parts Parts Diagram 02 - FRONT VIEW (SERIES 03)

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	<a href="#">Y052740</a>	<a href="#">62739</a>		Nut, Lock
002	204051	<a href="#">22204051</a>		Knob
003	<a href="#">204439</a>			Screw And Fstner Assembly
004	<a href="#">204445</a>			Screw And Fastener Assembly
005	<a href="#">210385</a>			Lock Nut For Adjustable Leg
006	<a href="#">210684</a>			Foot, Adjustable Leg
007	212276	<a href="#">W10116760</a>		Screw
008	<a href="#">212519</a>	<a href="#">488234</a>		Screw 8-32 X 1/4
009	212949	<a href="#">22001866</a>		Screw, Relay
010	<a href="#">213007</a>			Xfor Cabinet See Cabinet, Back
011	NLA		Not Available	GASKET UNDER CONTROL CENTER
012	<a href="#">213099</a>			Lens For Control Panel
013	<a href="#">213949</a>			Screw, No.8-18 X 5/16 Inch
014	Y302699	<a href="#">22003428</a>		Leg, Adjustable
015	NLA		Not Available	CONTROL CENTER-WHITE

016	<a href="#">Y303204</a>		Start Switch With Nuts
017	NLA	Not Available	CABINET-WHITE
018	NLA	Not Available	CABINET-ALMOND
019	NLA	Not Available	CABINET-HARVEST WHEAT
020	NLA	Not Available	TOP COVER-WHITE
021	NLA	Not Available	TOP COVER-ALMOND
022	NLA	Not Available	TOP COVER-HARVEST WHEAT
023	Y303420	Not Available	SELECTOR SWITCH
024	<a href="#">Y303703</a>		Pilot Light
025	Y304384	<a href="#">33001003</a>	Screen, Lint
026	<a href="#">Y304575</a>	<a href="#">W10169313</a>	Switch-Dor
027	Y304577	<a href="#">33001230</a>	Hinge, Door
028	Y304579	<a href="#">Y306668</a>	DOOR (WHT)
030	NLA	Not Available	DOOR-ALMOND
031	NLA	Not Available	DOOR-HARVEST WHEAT
032	NLA	Not Available	FRONT PANEL-WHITE
033	NLA	Not Available	FRONT PANEL-ALMOND
034	NLA	Not Available	FRONT PANEL-HARVEST WHEAT
035	NLA	Not Available	CONTROL COVER-WHITE
036	NLA	Not Available	CONTROL COVER-ALMOND
037	NLA	Not Available	CONTROL COVER-HARVEST WHEAT
038	Y304648	<a href="#">33001106</a>	Back, Tumbler
039	<a href="#">Y305086</a>		Adjustable Leg And Nut
040	NLA	Not Available	INNER DOOR WITH KNOB & SCRE
041	NLA	Not Available	KNOB AND SCREW
042	<a href="#">306436</a>		Door Latch Kit--W
043	NLA	Not Available	BACK FOR CONTROL PANEL
044	<a href="#">Y313340</a>		LABEL, LINT SCREEN INSTRUCTION
045	Y313541	<a href="#">33313541</a>	Seal- Tumbler
046	<a href="#">Y313907</a>		Fastener, Twin
047	<a href="#">Y313908</a>		DOOR PANEL-WHITE
048	NLA	Not Available	DOOR PANEL-ALMOND
049	NLA	Not Available	DOOR PANEL-HARVEST WHEAT
050	<a href="#">Y313910</a>		Clip, Door Liner To Outer Panel
051	<a href="#">Y313911</a>		Door Strike Retainer
052	NLA	Not Available	CONTROL PANEL
053	<a href="#">Y313927</a>		INSTRUCTION LABEL
054	<a href="#">Y314062</a>		Screw, Door Hinge And Panel
055	<a href="#">314077</a>		Door Seal
056	NLA	Not Available	GAS IGNITION LABEL
057	<a href="#">Y314137</a>		Foot, Rubber
058	NLA	Not Available	SCREW FOR DOOR KNOB---NA