



Maytag [Commercial Maytag DG33CA Dryer Parts](#) Parts Diagram 03 - TIMER
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	TOOL TO ADJUST TIMING SWITCH
002	NLA		Not Available	SCREW, No.5-40 X 3/8
003	Y330064			Pilot Light
004	Y330079		Not Available	SWITCH, PUSH-TO-START
005	330081			Timer - CA 60 Minutes
006	NLA		Not Available	PART NOT USED
007	NLA		Not Available	FRONT PANEL-WHITE
008	330108L		Not Available	FRONT PANEL-ALMOND
009	330108M		Not Available	FRONT PANEL-HARVEST WHEAT
010	Y330145		Not Available	CONTA ACCUMULATOR ASSEMBLY
011	330184			Timer Accumulator-25
012	NLA		Not Available	TIMER ACCUMULATOR (.25-.10)
013	NLA		Not Available	TIMER ACCUMULATOR (.10)
014	NLA		Not Available	TIMER ACCUMULATOR (.25)

015	Y330256		Not Available	KNOB, TIMER
016	Y330257			Timer
017	331014	8281196		Screw
018	331032	61002031		Screw, Handle
019	331036			Washer-Front Panel Screws
020	331041			Button-Push-To-Start Switch
021	NLA		Not Available	TIMER DIAL
022	331061			Knob For Temperature Contro
023	NLA		Not Available	KNOB, TIMER
024	NLA		Not Available	MOUNTING PLATE, TIMER
025	NLA		Not Available	TRIM BAR, UPPER PANEL
026	331101		Not Available	BEZEL FOR TIMER-ACCUMULATOR
027	NLA		Not Available	INSTRUCTION PLATE
028	331151			Lever-Temperature Control
029	NLA		Not Available	NUT
030	NLA		Not Available	MOUNTING PLATE, TIMER
031	NLA		Not Available	DECAL, FACE PLATE
032	NLA		Not Available	SCREW
033	NLA		Not Available	SCREW
034	NLA		Not Available	WASHER
035	NLA		Not Available	METER PLATE

