


# Maytag MDG12MNAGW 07 - CONTROL PANEL



Maytag [Commercial Maytag MDG12MNAGW Dryer Parts](#) Parts Diagram 07 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	<a href="#">33001710</a>			Panel, Control
002	<a href="#">215506</a>			Screw, Control Panel Overlay
003	<a href="#">215003</a>			Fastener, Panel And Bracket
004	<a href="#">33001280</a>			Console
005	212276	<a href="#">W10116760</a>		Screw
006	<a href="#">211252</a>			Screw, Ground Wire
007	<a href="#">205810</a>			Wire, Ground
008	NLA		Not Available	BRACKET, CONTROL PANEL (WHT)
009	<a href="#">306938</a>			Knob, Selector Switch
010	307237	<a href="#">W10327105</a>		Switch, Cycle Selection
011	<a href="#">Y313588</a>	<a href="#">488234</a>		Screw 8-32 X 1/4
012	<a href="#">33001522</a>			Harness, Wire
"	<a href="#">33001524</a>			Wire Harness, Main
013	306940	<a href="#">W10149462</a>		Switch, Push-To-Start
014	Y312706	<a href="#">422617</a>		Nut
015	<a href="#">312751</a>			Lockwasher, Start Switch

016	<a href="#">Y312702</a>		Knurled Nut, Start Switch
017	204075	Not Available	PILOT LAMP (DG MODELS ONLY)
"	22001365	<a href="#">W10139459</a>	Lamp-Indicator 230 V.
018	<a href="#">215564</a>		Lens, Indicator Light
019	<a href="#">305214</a>		Timer
"	<a href="#">Y305758</a>		Timer 240-50
020	314723	<a href="#">W10133501</a>	Cap, Knob
021	<a href="#">33001500</a>		Dial, Timer Indicator
022	<a href="#">Y313588</a>	<a href="#">488234</a>	Screw 8-32 X 1/4
023	<a href="#">312273</a>		Nut, Control Knob
024	<a href="#">314724</a>		Knob For Timer

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>