


Maytag MDG16CSAGW 01 - CONTROL PANEL



Maytag [Commercial Maytag MDG16CSAGW Dryer Parts](#) Parts Diagram 01 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	PANEL, CONTROL
002	215506			Screw, Control Panel Overlay
003	215506			Screw, Control Panel Overlay
004	22002329			Console
"	22002330	22002889		Console
"	22003089			Console
005	212276	W10116760		Screw
006	211252			Screw, Ground Wire
007	205810			Wire, Ground
008	33001959			Bracket, Back
"	33002522			Bracket, Back
"	NLA		Not Available	BRACKET, BACK (ALM)
009	306938			Knob, Selector Switch
010	307237	W10327105		Switch, Cycle Selection
"	33002276			Switch, Cycle Selector
011	Y313588	488234		Screw 8-32 X 1/4

012	33001963		Wire Harness, Main
"	33002244		Wire Harness, Main
"	33002245		Wire Harness, Main
"	NLA	Not Available	WIRE HARNESS, MAIN
013	306940	W10149462	Switch, Push-To-Start
014	Y312706	422617	Nut
015	312751		Lockwasher, Start Switch
016	Y312702		Knurled Nut, Start Switch
017	204075	Not Available	PILOT LAMP (DG MODELS ONLY)
"	22001365	W10139459	Lamp-Indicator 230 V.
018	215564		Lens, Indicator Light
019	16009021		Manual, Service-No Refund

the laundry company[®]

the laundry company[®]

the laundry company[®]