


Maytag MLE24PRAYW1 01 - LOWER CABINET AND FRONT PANEL PARTS



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

W10184604

2

Maytag [Commercial Maytag MLE24PRAYW1 Dryer Parts](#) Parts Diagram 01 - LOWER CABINET AND FRONT PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10184580		Not Available	Installation Instructions
"	W10135291		Not Available	Card Reader Installation Instructions
"	W10135168		Not Available	Tech Sheet
"	W10184604			Repair Parts List
2	3391915	681615		Screw
3	3390663	681414		Screw, 10AB X 1/2
4	3391846			Clip, Front Panel
5	8564010			Assembly, Switch And Actuator
6	697773	3395530		Screw
7	8310656			Cabinet
8	3392100	49621		Feet-Leveling
9	660658			Clamp, Motor Mounting 343481 685441
10	3387374			Spring, Idler

11	3389420		Retainer-Idler 1/4-20 X 1/16
13	W10141380	W10344192	Idler Assembly
14	3400077		Screw, 10-16 X 1/2
16	8539892		Wire-Motor To Belt Switch
17	98997		Clip, Harness Following Parts Optional Are Not Supplied On This Whirlpool Model. But Are Available For Purchase.
19	297092		Clip
24	3394331		Plate Cover
25	8564011		Bracket-Switch
27	W10139766	W10396034	Motor Assembly 60 Hz
28	W10167613		Wire, Belt Switch
29	3394341	W10299847	Pulley-Motor
30	W10131172		Belt, Drive
31	3390902		Clip, Door Hinge
32	W10135695		Bracket, Motor
33	3392186	4159590	Washer
34	693152		Bumper, Console
35	279731	49026	4" - 90° Elbow
36	697750	W10470674	Dryer Exhaust Kit
37	488729		Screw
38	8283298		Jumper, Door Switch
40	697215	3406797	Toe Panel
41	3406109	3406107	Door Switch Assembly
42	W10002600		Screw, 6-20 X 1 1/4
43	W10155571		Switch, Assembly
44	3387242		Seal, Front Panel
45	342055	488627	Screw
46	3388229		Retainer, Toe Panel
51	W10192882	W10242810	Panel
52	696144	279570	Latch
55	3390647	488729	Screw
56	W10169678		Harness
58	W10212660		Pad, Sound Dampening
59	3391943		Boot, Foot
60	3405160		Belt, Drive
61	3393657		Restrainer, Belt
NI	279818	W10470674	Dryer Exhaust Kit

the laundry company[®]