


Amana DG3020 09 - CLOTHES DRUM



CLOTHES DRUM

Amana [Residential Amana DG3020 Washer Parts](#) Parts Diagram 09 - CLOTHES DRUM
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|------------------------|-------------|---------------|------------------|
| 1 | 51881 | | | Seal, Front |
| 2 | 50169 | | | Strap, Retainer |
| 3 | 53135 | | | Assembly, Drum |
| 4 | 52310 | | | Spring |
| 5 | 50781 | | | Strap, Seal |
| 6 | 51883A | | | Assembly, Seal |
| 7 | 51201 | | Not Available | CLIP |
| 8 | 50168 | | | Spring |