


# Amana DG3630 12 - DRUM LIGHT & COVER PLATE



[Amana Residential Amana DG3630 Washer Parts](#) Parts Diagram 12 - DRUM LIGHT & COVER PLATE  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
3	54610		Not Available	PLUG BUTTON
4	Y00000000		Not Available	SEE NOTE FRONT FRAME AND AIR SHROUD