


# Amana LWC30AW (BOM: PLWC30AW) 01 - Agitator, Drive Bell, Washtub and Hub



Amana Residential Amana LWC30AW (BOM: PLWC30AW) Washer Parts Parts Diagram 01 - Agitator, Drive Bell, Washtub and Hub

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	27202	<a href="#">W10116787</a>		Screw
2	<a href="#">28094</a>			Gasket
3	39113	<a href="#">R9900144</a>		Kit- Wash
4	37411	<a href="#">27001052</a>		Balance Ring
5	37982P		Not Available	WASHTUB
6	39112	<a href="#">39371</a>		Filter Lin
7	646P3	<a href="#">R9900552</a>		Hub And Seal
8	29728	<a href="#">40008301</a>		Insert, Spline
9	Y29220	<a href="#">40016301</a>		Nut, Lock
10	36425	<a href="#">40016101</a>		Seal, Bell Drive
11	36443P	<a href="#">R9900189</a>		Kit, Drive Bell And Seal
12	34288	<a href="#">40065102</a>		Screw, Shoulder 1/4
13	<a href="#">36472</a>			O-Ring
14	36511	<a href="#">40008401</a>		Plug, Bell
15	36507	<a href="#">40000501W</a>		Agitator, Flex Vane

