


# Crosley CDE20P8WC 04 - HEATER

SECTION: HEATER  
MODEL: CDE20P8C



Issue Date: 2/91

Crosley [Residential Crosley CDE20P8WC Dryer Parts](#) Parts Diagram 04 - HEATER  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	53-0920	<a href="#">LA-1044</a>		Element
"	<a href="#">25-7863</a>			Screw
2	<a href="#">53-1232</a>			Heater Housing Assembly
"	25-7819	<a href="#">M0217225</a>		Screw
3	<a href="#">53-1493</a>			Thermostat
4	<a href="#">53-1181</a>			Bracket, Thermal Fuse
"	25-7741	<a href="#">W10116760</a>		Screw
5	53-0166	<a href="#">53-1518</a>		Block, Terminal
"	25-7803	<a href="#">3400074</a>		Screw
"	25-6124		Not Available	NUT
"	25-3123		Not Available	WASHER, CUP
"	<a href="#">25-3122</a>			Washer, Flat
"	25-0027	<a href="#">112432</a>		Nut
6	<a href="#">LA-1053</a>			Fuse Kit, Thermal
"	31001019		Not Available	CORD, POWER