


Crosley CDG20P8W 02 - CONTROL PANEL (ORIG. REV. A-D)



Crosley [Residential Crosley CDG20P8W Dryer Parts](#) Parts Diagram 02 - CONTROL PANEL (ORIG. REV. A-D)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	25-7702			Speedclip, End Cap To Control Panel
"	25-7793			Screw
"	53-1286		Not Available	CONTROL PANEL
2	53-0264			RH Endcap
"	35-2487	21001451		Cap- End
3	35-2488	21001452		Cap- End
"	25-7760			Screw
"	53-0265			LH Endcap
"	53-0278		Not Available	TRIM, END CAP (LT)
"	53-0277		Not Available	TRIM, END CAP (RT)
4	53-0365	53-1676		Shield, Control
"	25-7702			Speedclip, End Cap To Control Panel
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	53-1676			Shield, Control

5	25-0205	216412		Screw, Bracket To Timer
"	53-1300		Not Available	TIMER
"	63-5685	63-5613		Timer
6	53-0653	31001219		Knob Ski
7	35-0145	21001283		Knob, Selector---Piq
8	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	63-6731	53-1639		Buzzer Assembly
9	25-7702			Speedclip, End Cap To Control Panel
10	53-1266		Not Available	ROTARY SWITCH
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
11	53-0346	53-1263		Rotary Switch
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
12	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	25-3457			Screw, Sems
"	34-9487		Not Available	PLATE, REINFORCEMENT
"	25-7697	25-2219		Screw
"	53-0268	21001460		Shield, Rear
"	35-2688	21001460		Shield, Rear
"	25-7851			Speedclip, End Cap To Top
"	25-7852			Speedclip, Rr Shld To End Cap
"	25-7435	33002917		Screw, No.10-16

the laundry company[®]

the laundry company[®]