



**NON – ILLUSTRATED
PARTS**

Includes

Optional Parts

Parts Not Included

Miscellaneous Parts



[Crosley Residential Crosley CED147HXW0 Dryer Parts](#) Parts Diagram 04 - OPTIONAL PARTS (NOT INCLUDED)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
NI	279948	4392065		Kit, Dryer Repair
"	3406839			Dry Rack Assembly
"	8522199			Accessory Parts
"	72017			Paint, Touch-Up
"	350930			Paint, Pressurized Spray B
"	350938			Paint, Pressurized Spray B
"	799344			Paint, Touch-Up)

