


Magic Chef W18JA1 02 - CONTROL PANEL



Magic Chef [Residential Magic Chef W18JA1 Washer Parts](#) Parts Diagram 02 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	25-7702			Speedclip, End Cap To Control Panel
"	25-7793			Screw
"	35-2170		Not Available	CONTROL PANEL
2	53-0265			LH Endcap
"	53-0264			RH Endcap
3	34-9487		Not Available	PLATE, REINFORCEMENT
"	25-7697	25-2219		Screw
"	25-7851			Speedclip, End Cap To Top
4	25-7435	33002917		Screw, No.10-16
"	25-7852			Speedclip, Rr Shld To End Cap
5	53-0277		Not Available	TRIM, END CAP (RT)
"	53-0278		Not Available	TRIM, END CAP (LT)
6	25-7760			Screw
7	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping

8	25-7702		Speedclip, End Cap To Control Panel
9	53-0365	53-1676	Shield, Control
10	53-0268	21001460	Shield, Rear
"	25-3457		Screw, Sems
"	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
11	35-2208		Not Available TIMER
12	25-0088	489483	Screw 10-32 X 1/2
13	35-2254	12500058	Knob Ski
14	W10124350		Not Available NOT REQUIRED PART OR SEE NOTE
15	35-2145	21001554	Switch, Water Level
16	35-2519		Not Available MANUAL, USE & CARE
"	35-2185	21001283	Knob, Selector---Piq
"	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping

