


Magic Chef W205KAC 02 - CONTROL PANEL



Magic Chef [Residential Magic Chef W205KAC Washer Parts](#) Parts Diagram 02 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	25-7793			Screw
"	25-7702			Speedclip, End Cap To Control Panel
"	35-3920		Not Available	PANEL, CONTROL
2	35-2487	21001451		Cap- End
"	35-2488	21001452		Cap- End
3	25-7697	25-2219		Screw
"	25-7851			Speedclip, End Cap To Top
4	25-7435	33002917		Screw, No.10-16
"	25-7852			Speedclip, Rr Shld To End Cap
5	53-2412			End Trim RH
"	53-2413			End Trim L.H.
6	25-7760			Screw
7	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
8	25-7702			Speedclip, End Cap To Control Panel

9	53-2504	31001193	Pad, Shield
"	53-1676		Shield, Control
10	25-3457		Screw, Sems
"	25-7853	25-7933	Ring, Retaining
"	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	35-2688	21001460	Shield, Rear
11	35-3840		Timer
12	25-0205	216412	Screw, Bracket To Timer
13	35-3964	21001497	Skirt Ri
14	35-3962	21001282	Knob, Timer
15	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	35-0124	Not Available	SWITCH, WATER TEMPERATURE
16	35-3960	21001283	Knob, Selector---Piq
17	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	35-3691	21001554	Switch, Water Level
18	21001053	Not Available	MANUAL, USE & CARE
"	21001049	Not Available	MANUAL, USE & CARE
19	16000329	Not Available	GUIDE, QUICK REF. - MAGIC CHEF

