


Maytag DE408 02 - FRONT PANEL & DOOR ASSEMBLY



Maytag Residential Maytag DE408 Dryer Parts Parts Diagram 02 - FRONT PANEL & DOOR ASSEMBLY
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	204439			Screw And Fstner Assembly
3	212982	22001650		Fastener, Spring
10	303942		Not Available	KNOB AND SCREW
11	Y304575	W10169313		Switch-Dor
13	Y304577	33001230		Hinge, Door
14	Y304579			DOOR (WHT)
15	304579F		Not Available	DOOR-LIGHT GOLD
16	304579J		Not Available	DOOR-LIGHT AVOCADO
17	304579L		Not Available	DOOR-ALMOND
18	304579M		Not Available	DOOR-HARVEST WHEAT
19	304579N		Not Available	DOOR-FRESH AVOCADO
26	304595	3369903		Dishrack
27	304595H		Not Available	FRONT PANEL-SHADED GOLD
28	304595K		Not Available	FRONT PANEL-SHADED AVOCADO
29	304595L		Not Available	FRONT PANEL-ALMOND

30	304594M	3369903		Dishrack
31	304594N		Not Available	FRONT PANEL-FRESH AVOCADO
32	305835		Not Available	INNER DOOR WITH KNOB & SCRE
33	306436			Door Latch Kit--W
34	Y310376			Clip, Door Switch Harness
37	Y313340			LABEL, LINT SCREEN INSTRUCTION
38	Y313907			Fastener, Twin
39	Y313908			DOOR PANEL-WHITE
40	313908F		Not Available	DOOR PANEL-LIGHT GOLD
41	313908J		Not Available	DOOR PANEL-LIGHT AVOCADO
42	313908L		Not Available	DOOR PANEL-ALMOND
43	313908M		Not Available	DOOR PANEL-HARVEST WHEAT
44	313908N		Not Available	DOOR PANEL-FRESH AVOCADO
45	Y313910			Clip, Door Liner To Outer Panel
46	Y313911			Door Strike Retainer
47	Y313927			INSTRUCTION LABEL
48	Y314062			Screw, Door Hinge And Panel
49	314077			Door Seal
50	314119		Not Available	GAS IGNITION LABEL
51	314286			Seal For Front Panel
52	314347	400021-1		Screw

the laundry company[®]

the laundry company[®]