


Maytag DG33CA 01 - FRONT VIEW-DOOR OPEN



Maytag Residential Maytag DG33CA Dryer Parts Parts Diagram 01 - FRONT VIEW-DOOR OPEN
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	213966	3400014		Screw
002	Y330064			Pilot Light
003	NLA		Not Available	LEVELING LEG
004	Y330079		Not Available	SWITCH, PUSH-TO-START
005	Y330080		Not Available	SPIDER & SHAFT ASSEMBLY
006	Y330087			Drum Assembly Complete
007	NLA		Not Available	HINGE, DOOR
008	Y330102			FRONT PANEL-WHITE
009	NLA		Not Available	(ALMOND)
010	NLA		Not Available	(HARVEST WHEAT)
011	NLA		Not Available	FRONT PANEL-WHITE
012	330108L		Not Available	FRONT PANEL-ALMOND
013	330108M		Not Available	FRONT PANEL-HARVEST WHEAT
014	Y330217			Lock
015	Y330218			Lock

016	NLA	Not Available	DOOR ASSEMBLY (WHITE)
017	NLA	Not Available	(ALMOND)
018	NLA	Not Available	(HARVEST WHEAT)
019	Y330241	Not Available	PANEL, FRONT (WHITE)
020	330241L	Not Available	(ALMOND)
021	NLA	Not Available	(HARVEST WHEAT)
022	331014	8281196	Screw
023	331032	61002031	Screw, Handle
024	331036		Washer-Front Panel Screws
025	331041		Button-Push-To-Start Switch
026	331061		Knob For Temperature Contro
027	331064	Not Available	MAGNET FOR DOOR HANDLE
028	331071	Not Available	STRIKE PLATE FOR DOOR
029	NLA	Not Available	TRIM STRIP, LOWER FRONT PANEL
030	NLA	Not Available	TRIM BAR, UPPER PANEL
031	NLA	Not Available	POLE BLOCK, DOOR MAGNET
032	331101	Not Available	BEZEL FOR TIMER-ACCUMULATOR
033	NLA	Not Available	INSTRUCTION PLATE
034	NLA	Not Available	HINGE RIVET
035	331151		Lever-Temperature Control
036	331167		Gasket For Door-Outer
037	331185		Hinge Pin For Door
038	331192	Not Available	GLASS, LOADING DOOR
039	331193	Not Available	COVER FOR DOOR SWITCH BOX
040	331199	Not Available	GASKET FOR DOOR GLASS
041	331200		Handle, Door
042	331204	61003351	Screw, Handle To Frame
043	NLA	Not Available	SCREW, DOOR HANDLE
044	NLA	Not Available	ROLL PIN, DOOR HANDLE

