


Maytag DG410 03 - FRONT VIEW



Maytag Residential Maytag DG410 Dryer Parts Parts Diagram 03 - FRONT VIEW
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
2	204439			Screw And Fstner Assembly
3	204445			Screw And Fastener Assembly
4	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
5	213007			Xfor Cabinet See Cabinet, Back
6	302542		Not Available	PART NOT USED. (DG ONLY)
7	302542L		Not Available	PART NOT USED. (DG ONLY)
8	302542M		Not Available	ACCESS DOOR-HARVEST WHEAT
9	Y303361		Not Available	BASE ASSY. (UPPER & LOWER)
10	Y304579			DOOR (WHT)
13	304594			Front Panel-White
16	304595	3369903		Dishrack
17	304595L		Not Available	FRONT PANEL-ALMOND
18	304595M		Not Available	FRONT PANEL-HARVEST WHEAT

19	Y305086		Adjustable Leg And Nut
20	Y305190	307104	Top Cover Assembly
23	Y305193		Console
26	305302		Not Available CABINET-WHITE
29	303942		Not Available KNOB AND SCREW
30	Y310632	1163839	Screw
31	Y313559		Screw
32	Y313908		DOOR PANEL-WHITE
35	Y314137		Foot, Rubber

