

Maytag DG713 02 - DOOR



30

Maytag [Residential Maytag DG713 Dryer Parts](#) Parts Diagram 02 - DOOR
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	314119		Not Available	GAS IGNITION LABEL
2	Y313927			INSTRUCTION LABEL
3	306436			Door Latch Kit--W
4	314286			Seal For Front Panel
5	Y310376			Clip, Door Switch Harness
6	212982	22001650		Fastener, Spring
7	314077			Door Seal
8	314347	400021-1		Screw
9	Y305754	W10169313		Switch-Dor
10	Y314062			Screw, Door Hinge And Panel
11	Y313910			Clip, Door Liner To Outer Panel
12	Y313911			Door Strike Retainer
13	303942		Not Available	KNOB AND SCREW
14	Y313908			DOOR PANEL-WHITE
15	Y304579			DOOR (WHT)
"	Y306668			DOOR (WHT)

16	305835		Not Available	INNER DOOR WITH KNOB & SCRE
"	306676		Not Available	INNER DOOR WITH KNOB
17	302542		Not Available	PART NOT USED. (DG ONLY)
18	Y304577	33001230		Hinge, Door
19	Y313907			Fastener, Twin
20	304594			Front Panel-White
21	204439			Screw And Fstner Assembly
22	212949	22001866		Screw, Relay
23	312301		Not Available	BUSHING FOR ACCESS STUD
24	312369			Sleeve, Access Panel Stud Part Not Used

the laundry company[®]

the laundry company[®]

the laundry company[®]