


# Maytag LDE8420ADW 01 - CABINET-FRONT

Section: CABINET-FRONT

P/N 1600028

Models: ALL MODELS



Maytag Residential Maytag LDE8420ADW Dryer Parts Parts Diagram 01 - CABINET-FRONT  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">Y305193</a>			Console
2	<a href="#">Y313559</a>			Screw
3	<a href="#">307104</a>			Top Cover Assembly
4	<a href="#">308000</a>			Panel, Front
5	<a href="#">314946</a>			Handle White
6	<a href="#">314966</a>			Panel, Outer
"	Y307111		Not Available	DOOR ASSY. COMPLETE (WHT)
7	307099	<a href="#">33001230</a>		Hinge, Door
8	<a href="#">204439</a>			Screw And Fstner Assembly
9	302542		Not Available	PART NOT USED. (DG ONLY)
10	Y310632	<a href="#">1163839</a>		Screw
11	Y303361		Not Available	BASE ASSY. (UPPER & LOWER)
12	<a href="#">Y314137</a>			Foot, Rubber
13	<a href="#">Y305086</a>			Adjustable Leg And Nut
14	Y052740	<a href="#">62739</a>		Nut, Lock

15	<a href="#">213007</a>		Xfor Cabinet See Cabinet, Back
16	<a href="#">307124</a>		Cabinet
17	<a href="#">204445</a>		Screw And Fastener Assembly
18	211294	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping

