


# Maytag LDG24CA 02 - CA CONTROL PANEL



Maytag Residential Maytag LDG24CA Dryer Parts Parts Diagram 02 - CA CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	204075		Not Available	PILOT LAMP (DG MODELS ONLY)
002	<a href="#">205810</a>			Wire, Ground
003	<a href="#">211252</a>			Screw, Ground Wire
004	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
005	212276	<a href="#">W10116760</a>		Screw
006	<a href="#">212277</a>			Screw, No.8 X 1/2 Inch
007	<a href="#">215003</a>			Fastener, Panel And Bracket
008	<a href="#">215564</a>			Lens, Indicator Light
009	Y305190	<a href="#">307104</a>		Top Cover Assembly
010	NLA		Not Available	TOP COVER-ALMOND
011	NLA		Not Available	TOP COVER-HARVEST WHEAT
012	NLA		Not Available	CONSOLE-WHITE
013	NLA		Not Available	CONSOLE-ALMOND
014	NLA		Not Available	CONSOLE-HARVEST WHEAT

015	<a href="#">305214</a>		Timer
016	305215	<a href="#">305214</a>	Timer
018	<a href="#">306938</a>		Knob, Selector Switch
019	307237	<a href="#">W10327105</a>	Switch, Cycle Selection
020	306940	<a href="#">W10149462</a>	Switch, Push-To-Start
023	NLA	Not Available	MAIN WIRE HARNESS - DG
024	<a href="#">312273</a>		Nut, Control Knob
025	<a href="#">Y312702</a>		Knurled Nut, Start Switch
026	Y312706	<a href="#">422617</a>	Nut
027	<a href="#">312751</a>		Lockwasher, Start Switch
028	Y313588	<a href="#">488234</a>	Screw 8-32 X 1/4
029	Y314322	<a href="#">211251</a>	Screw, Transformer
030	314723	<a href="#">W10133501</a>	Cap, Knob
031	<a href="#">314724</a>		Knob For Timer
032	314725	<a href="#">33001500</a>	Dial, Timer Indicator
033	314909	<a href="#">33001021</a>	Panel, Control
034	NLA	Not Available	BACK-UP PLATE (WHITE)
035	NLA	Not Available	BACK UP PLATE-ALMOND
036	NLA	Not Available	BACK UP PLATE-HARVEST WHEAT

