


# Maytag LDG8624AAL 02 - CONTROL PANEL



Maytag Residential Maytag LDG8624AAL Dryer Parts Parts Diagram 02 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">214872</a>			Palnut, End Cap Note: Nut, Lamp Holder
2	33001237		Not Available	PLATE, SUPPORT
3	314728	<a href="#">210932</a>		Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
4	<a href="#">22001288</a>			End Cap, Control Panel
"	<a href="#">22001290</a>			End Cap, Control Panel
5	<a href="#">214894</a>			Fastener, End Cap
6	<a href="#">33001083</a>			Panel, Control
7	33001182		Not Available	SKIRT, TIMER DIAL (BLK)
8	<a href="#">315041</a>			Knob, Timer
9	<a href="#">312273</a>			Nut, Control Knob
10	216193		Not Available	CAP, TIMER KNOB (BLK)
11	<a href="#">33001184</a>			Button
12	<a href="#">214897</a>			Pad, Control Panel
13	315317	<a href="#">488234</a>		Screw 8-32 X 1/4
14	<a href="#">33001036</a>			Timer

15	210186	<a href="#">3370225</a>		Screw
16	<a href="#">204807</a>			Ground Wire, Supp. Plte To Top Cover
17	315317	<a href="#">488234</a>		Screw 8-32 X 1/4
18	Y308205	<a href="#">33001623</a>		Buzzer, Non-Adjustable
19	315317	<a href="#">488234</a>		Screw 8-32 X 1/4
20	33001232		Not Available	SWITCH, PUSH TO START
21	33001550		Not Available	HARNES, WIRE
"	33001147		Not Available	WIRE HARNES, MAIN
"	33001355		Not Available	WIRE HARNES, MAIN
22	<a href="#">22001267</a>			Knob, Selector Switch
23	33001225		Not Available	SWITCH, TEMP. (4 POSITION)
24	315317	<a href="#">488234</a>		Screw 8-32 X 1/4
25	<a href="#">33001046</a>			Display, Dryness Assembly
26	<a href="#">33001212</a>			Board, Control-Moisture Sensor
27	315317	<a href="#">488234</a>		Screw 8-32 X 1/4
28	<a href="#">33001105</a>			Resistor

