

# Maytag MDG10CSAGL 03 - CABINET (FRONT)



Maytag [Residential Maytag MDG10CSAGL Dryer Parts](#) Parts Diagram 03 - CABINET (FRONT)  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	CONSOLE (WHT)
002	212276	<a href="#">W10116760</a>		Screw
003	33001163		Not Available	COVER, TOP (WHT)
"	33001164		Not Available	COVER, TOP (ALM)
004	NLA		Not Available	PANEL, FRONT (WHT)
005	<a href="#">33001241</a>			Handle, Door
"	33001254	<a href="#">37001047</a>		Handle, Door
006	<a href="#">214354</a>			Screw, Top Cover To Cabnt.
007	<a href="#">33001230</a>			Hinge, Door
008	<a href="#">204439</a>			Screw And Fstner Assembly
009	<a href="#">215075</a>			Fastener, Control Panel To Console
010	<a href="#">Y313561</a>			Screw---NA
"	Y310632	<a href="#">1163839</a>		Screw
011	Y303361		Not Available	BASE ASSY. (UPPER & LOWER)
012	<a href="#">Y314137</a>			Foot, Rubber

013	<a href="#">Y305086</a>		Adjustable Leg And Nut	
014	Y052740	<a href="#">62739</a>	Nut, Lock	
015	<a href="#">213007</a>		Xfor Cabinet See Cabinet, Back	
016	NLA		Not Available	CABINET (WHT)
017	210186	<a href="#">3370225</a>		Screw
018	33001132	<a href="#">33002342</a>		Plug, Sifht Hole
"	33001168		Not Available	PLUG, SIGHT HOLE (ALM)

