


# Maytag MDG16CSDWQ 01 - CONTROL PANEL



Maytag [Residential Maytag MDG16CSDWQ Dryer Parts](#) Parts Diagram 01 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	<a href="#">33002938</a>			Facia - Cs
002	<a href="#">215506</a>			Screw, Control Panel Overlay
003	<a href="#">215506</a>			Screw, Control Panel Overlay
004	22002925	<a href="#">3370225</a>		Screw
"	<a href="#">22003088</a>			Console
"	<a href="#">22003089</a>			Console
"	<a href="#">33001948</a>			Transformer Lower
005	212276	<a href="#">W10116760</a>		Screw
006	<a href="#">211252</a>			Screw, Ground Wire
007	<a href="#">205810</a>			Wire, Ground
008	<a href="#">33002521</a>			Bracket, Back
"	<a href="#">33002522</a>			Bracket, Back
009	<a href="#">306938</a>			Knob, Selector Switch
010	307237	<a href="#">W10327105</a>		Switch, Cycle Selection
"	<a href="#">33002276</a>			Switch, Cycle Selector
011	Y313588	<a href="#">488234</a>		Screw 8-32 X 1/4

012	<a href="#">33002244</a>		Wire Harness, Main
"	<a href="#">33002771</a>		Harness, Wire Main
013	306940	<a href="#">W10149462</a>	Switch, Push-To-Start
014	Y312706	<a href="#">422617</a>	Nut
015	<a href="#">312751</a>		Lockwasher, Start Switch
016	<a href="#">Y312702</a>		Knurled Nut, Start Switch
017	22001365	<a href="#">W10139459</a>	Lamp-Indicator 230 V.
"	33002798	<a href="#">Y303703</a>	Pilot Light
018	<a href="#">215564</a>		Lens, Indicator Light
019	<a href="#">16009021</a>		Manual, Service-No Refund

