


Maytag MDG27PCABL 01 - FRONT



2

Maytag [Residential Maytag MDG27PCABL Dryer Parts](#) Parts Diagram 01 - FRONT
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	306398			Relay, Heater
"	Y251119	3177991		Screw
002	901961	W10133335		Relay, Motor
"	Y251119	3177991		Screw
003	314627			Bracket, Relays
"	Y310632	1163839		Screw
004	NLA		Not Available	RELAY COVER
"	Y310632	1163839		Screw
005	NLA		Not Available	NAME PLATE
006	NLA		Not Available	PANEL, FRONT UPPER (WHITE)
007	212982	22001650		Fastener, Spring
008	Y310376			Clip, Door Switch Harness
009	307104			Top Cover Assembly
"	NLA		Not Available	(ALMOND)
010	NLA		Not Available	TOP COVER PLATE
"	Y313559			Screw

011	204445			Screw And Fastener Assembly
"	213007			Xfor Cabinet See Cabinet, Back
"	NLA		Not Available	CABINET, UPPER (WHITE)
012	306261			Base Assembly, Upper Dryer
"	314663	214354		Screw, Top Cover To Cabnt.
013	310933	33002194		Nut, Speed
014	NLA		Not Available	COUPLING COLLAR-WHITE
"	Y310632	1163839		Screw
015	NLA		Not Available	CABINET, LOWER (WHITE)
016	Y302699	22003428		Leg, Adjustable
017	210684			Foot, Adjustable Leg
018	210385			Lock Nut For Adjustable Leg
019	NLA		Not Available	DOOR, ACCESS (WHITE)
020	204439			Screw And Fstner Assembly
"	NLA		Not Available	PANEL, FRONT (WHITE)
021	NLA		Not Available	RETAINER, FRONT PANEL
022	314522			Grommet, Strain Relief
023	NLA		Not Available	UPPER CONTROL EXTRUSION
024	314967		Not Available	DOOR W/WINDOW OUTER HALF (WHT)
"	NLA		Not Available	DOOR ASSY. COMPLETE (WHITE)
025	308069		Not Available	DOOR, INNER W/GASKET
026	314939			Handle, Door
"	314974			Handle, Door

the laundry company[®]

the laundry company[®]