


Maytag MDG8000AWW 03 - CONTROL PANEL



Maytag [Residential Maytag MDG8000AWW Dryer Parts](#) Parts Diagram 03 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y22002339	8534058		Screw
"	33002330			Panel, Control
2	33001621			Skirt, Timer Dial
3	22001659			Timer Knob - Grey
4	22001664			Timer Knob Insert/Cap
5	33001619	37001071		Button, Push-To-Start
6	33001690	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
7	33001730			Timer
8	22002529		Not Available	CONSOLE BACK PANEL
"	216423	3370225		Screw
9	33002286		Not Available	CONSOLE (WHT)
10	33001861	33001618		Switch- PU
11	33002420			Wire Harness, Main Note: Wire Harness, Main
12	33002414			Switch, Option 4 Pos
13	22001788			Button, Switch

14	22001789		Button, Switch
15	33002389		Dryness Display Control Note: Display, Dryness
16	33002417		2 Pos. Rocker Switch Note: Switch, Rocker
17	33001848		Signal, End Of Cycle
18	33001860	W10116760	Screw
19	33001656		Switch, Temp Note: Switch, Inf. Temp
20	22001948		Lens, Indicator Light
"	22001403		Light, Indicator
21	33002555	Not Available	MANUAL, USE & CARE (FRCH)
"	33002411		Manual, Use And Care

the laundry company[®]

the laundry company[®]

the laundry company[®]