


# Maytag MDG8500BWW 03 - CONTROL PANEL



Maytag [Residential Maytag MDG8500BWW Dryer Parts](#) Parts Diagram 03 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	33002485	<a href="#">33002330</a>		Panel, Control
"	Y22002339	<a href="#">8534058</a>		Screw
2	<a href="#">33001621</a>			Skirt, Timer Dial
3	<a href="#">22001659</a>			Timer Knob - Grey
4	<a href="#">22001664</a>			Timer Knob Insert/Cap
5	33001619	<a href="#">37001071</a>		Button, Push-To-Start
6	33001690	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
7	<a href="#">33001730</a>			Timer
8	22002529		Not Available	CONSOLE BACK PANEL
"	216423	<a href="#">3370225</a>		Screw
9	33002286		Not Available	CONSOLE (WHT)
10	33001861	<a href="#">33001618</a>		Switch- PU
11	<a href="#">33002420</a>			Wire Harness, Main Note: Wire Harness, Main
12	<a href="#">33002414</a>			Switch, Option 4 Pos
13	<a href="#">22001788</a>			Button, Switch

14	<a href="#">22001789</a>		Button, Switch
15	<a href="#">33002389</a>		Dryness Display Control Note: Display, Dryness
16	<a href="#">33002417</a>		2 Pos. Rocker Switch Note: Switch, Rocker
17	<a href="#">33001848</a>		Signal, End Of Cycle
18	33001860	<a href="#">W10116760</a>	Screw
19	<a href="#">33001656</a>		Switch, Temp Note: Switch, Inf. Temp
20	<a href="#">22001948</a>		Lens, Indicator Light
"	<a href="#">22001403</a>		Light, Indicator
21	33002557	Not Available	MANUAL, USE & CARE (FRCH)
"	33002486	Not Available	MANUAL, USE & CARE
"	33002488	Not Available	MANUAL U & C, DRYING RACK

