


Whirlpool GGQ8821LW1 01 - TOP AND CONSOLE PARTS



03-03 Litho in U.S.A. (djc)

1

Part No. 8180011

Whirlpool Residential Whirlpool GGQ8821LW1 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	LIT8541831		Not Available	Literature Parts (Wiring Diagram)
"	LIT8535837		Not Available	Literature Parts (Guide, Use & Care)
"	LIT8535841		Not Available	Literature Parts (Instructions, Installation)
"	N/A		Not Available	Following May Be Purchased DO-IT-YOURSELF REPAIR MANUALS
"	LIT677818	677818L		Diy
2	8317305	285909		Panel-Rear
3	3406725			Timer Assembly
4	3400859			Screw, Grounding
5	3398094			Switch, Push To Start
6	3391885			Connector, Edge
7	3395683			Receptacle, Multi-Terminal
8	8271359	279962		Endcap
"	3956023	285980		Endcap

9	8271316		Bracket, Control
10	3390646	W10139210	Screw, 8-18 X 5/16
11	3401850		Harness-Gas
12	388326		Screw, 8-18 X 1.25
13	3405155		Switch, Temperature
14	3391018		Tie Cable
15	8538957		Knob, Control
16	3397269		Connector, Timer
17	717252		Receptacle, Terminal
18	3403499		Connector, 2-Postion
19	8299951		Harness, Wiring
20	8538953		Timer Knob Assembly
21	693995		Screw, Hex Head
22	8318255	8568314	Strap, Console
23	357213		Nut, Push-In
24	8535848	8563987	Top
"	8535850	8563989	Top
25	3405152		Switch, Wrinkle Shield
26	8271365	279962	Endcap
"	3956024	285980	Endcap
27	3936144		Do-It-Yourself Repair Manuals
28	3403498		Connector, 3-Position
29	3390537	8558178	Control, Electronic
30	694419		Mini-Buzzer
31	8532645		Panel, Control
32	3405154		Switch Rotary
33	8538959		Knob, Push-To-Start
34	697779		Plug, 3-Way
35	3390647	488729	Screw
36	8317340		Cover, Terminal Block
37	3401144		Connector
38	3390814	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
39	3955776		Medallion
40	3347243		Block, Disconnect
41	3394427		Clip-Harness
42	8536939		Clip, Knob
44	94614		Terminal
45	688805		Clip, Spring Knob

