


# Whirlpool GGW9200LW1 01 - TOP AND CONSOLE PARTS



## TOP AND CONSOLE PARTS

For Models: GGW9200LW1, GGW9200LQ1, GGW9200LL1, GGW9200LT1  
(White/Platinum) (White/Blue) (Pewter) (Biscuit)

GAS DRYER



05-03 Printed in U.S.A. (djc)

1

Part No. 8180004 Rev. A

Whirlpool [Residential Whirlpool GGW9200LW1 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	LIT8542742		Not Available	Literature Parts (Use & Care Guide)
"	LIT8541834		Not Available	Literature Parts (Tech Sheet)
2	8519251	<a href="#">W10117263</a>		Top
"	3980096	<a href="#">3980357</a>		Top
"	8519252	<a href="#">3979307</a>		Top
3	<a href="#">8299950</a>			Harness, Main
4	<a href="#">8530587</a>			Panel, Console
"	<a href="#">8530588</a>			Panel, Console
"	<a href="#">3980188</a>			Panel, Console
"	3979788		Not Available	Panel, Console (Biscuit)
5	<a href="#">3394427</a>			Clip-Harness
6	<a href="#">8519271</a>			Bracket, Console
7	<a href="#">353424</a>			Plug, Terminal
8	<a href="#">94614</a>			Terminal
9	<a href="#">3936144</a>			Do-It-Yourself Repair Manuals
10	94613	<a href="#">596797</a>		Terminal

11	3390647	<a href="#">488729</a>	Screw
12	488886	<a href="#">488787</a>	Screw
13	<a href="#">8519406</a>		Bezel, Cycle
14	<a href="#">3936150</a>		Connector, 7-Circuit
15	<a href="#">3395683</a>		Receptacle, Multi-Terminal
16	<a href="#">8281225</a>		Screw, 8-18 X 1/2
17	<a href="#">2203186</a>		Connector, 5-Circuit
18	46197020472	<a href="#">8181859</a>	Knob, Control
"	46197020471	<a href="#">8181881</a>	Knob, Control
"	46197020742	<a href="#">8182050</a>	Knob, Control
"	46197020741	<a href="#">8182049</a>	Knob, Control
19	<a href="#">8530589</a>		User Interface
"	<a href="#">8530590</a>		User Interface
"	<a href="#">3980189</a>		User Interface
"	<a href="#">3979789</a>		User Interface
20	<a href="#">8530591</a>		Button, Start
21	<a href="#">8530592</a>		Button, Pause/Cancel

