


# Whirlpool GGW9250PT2 02 - CABINET PARTS



8180946

3

Whirlpool Residential Whirlpool GGW9250PT2 Dryer Parts Parts Diagram 02 - CABINET PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">8317340</a>			Cover, Terminal Block
2	3390814	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
3	697776	<a href="#">4331106</a>		Screw, No.10-32 X 7/16
4	8519213	<a href="#">W10131287</a>		Panel
"	8519217	<a href="#">3980359</a>		Panel
"	8519214	<a href="#">W10131288</a>		Panel
5	3394881	<a href="#">279782</a>		Switch-Lid
6	8521959	<a href="#">W10121663</a>		Dryer Rack
7	8519209	<a href="#">W10131287</a>		Panel
"	8519216	<a href="#">3980358</a>		Panel
"	8519210	<a href="#">W10131288</a>		Panel
8	3392100	<a href="#">49621</a>		Feet-Leveling
"	<a href="#">279810</a>			Foot-Optional
9	<a href="#">660658</a>			Clamp, Motor Mounting 343481 685441
10	<a href="#">3387374</a>			Spring, Idler

11	<a href="#">3389420</a>		Retainer-Idler 1/4-20 X 1/16
12	697750	<a href="#">W10470674</a>	Dryer Exhaust Kit
"	<a href="#">3979261</a>		Plug, Multivalent
"	<a href="#">3388311</a>		Plug, Multivalent
13	3388672	<a href="#">279640</a>	Pulley-Idr
14	<a href="#">3978776</a>		Bracket, Gas Pipe Switch
15	<a href="#">8066120</a>		Lever, Door Switch
16	<a href="#">3394081</a>		Wire, Broken Belt Switch
17	8564132	<a href="#">8564134</a>	Board, Sound Dampening
18	<a href="#">233520</a>		Washer, Thrust
19	<a href="#">8283288</a>		Wire, Jumper
20	<a href="#">690997</a>		Washer, Thrust
21	8066115	<a href="#">3394331</a>	Plate Cover
22	<a href="#">8529053</a>		Ramp, Door Door Switch
23	<a href="#">8521961</a>		Support, Dry Rack
24	<a href="#">693995</a>		Screw, Hex Head
25	8521957	<a href="#">W10121663</a>	Dryer Rack
26	<a href="#">3393657</a>		Restrainer, Belt
27	8538263	<a href="#">279787</a>	Motor-Drve
28	<a href="#">3398948</a>		Wire, Jumper
29	<a href="#">3389729</a>		Pulley, Motor
30	3387610	<a href="#">661570</a>	Belt
31	<a href="#">8529757</a>		Bracket, Burner
32	<a href="#">3387118</a>		Bracket, Motor
33	3401401	<a href="#">3401402</a>	Cord, Power
34	<a href="#">49026</a>		4" - 90° Elbow
36	<a href="#">3395532</a>		Exhaust Pipe And Bracket
37	<a href="#">3395534</a>		Exhaust Pipe
38	3395535	<a href="#">8563749</a>	Exhaust Pipe
39	3388674	<a href="#">W10118756</a>	Idler Bracket
41	8519323	<a href="#">8283288</a>	Wire, Jumper
42	<a href="#">98129</a>		Screw, 6-20 X 1 1/16
43	3390647	<a href="#">488729</a>	Screw
44	<a href="#">3387242</a>		Seal, Front Panel
45	3393008	<a href="#">308685</a>	Side Trim )
46	<a href="#">8519459</a>		Clip, Toe Panel
50	<a href="#">8519207</a>		Base, Cabinet
51	8562167	<a href="#">280096</a>	Panel
"	8562169	<a href="#">280098</a>	Panel
"	8562168	<a href="#">280097</a>	Panel
52	696144	<a href="#">279570</a>	Latch
55	<a href="#">8299929</a>		Harness, Digital Interface
56	8519273	<a href="#">W10119274</a>	Bracket, Control
57	<a href="#">8546219</a>		Control Board
59	<a href="#">3400826</a>		Screw, 8-18 X 3/4
61	<a href="#">8519233</a>		Toe, Panel
"	<a href="#">3980095</a>		Toe, Panel
"	<a href="#">8519234</a>		Toe, Panel
62	8519219	<a href="#">280036</a>	Panel-Rear
63	<a href="#">692400</a>		Nut, Push-In
64	343641	<a href="#">681414</a>	Screw, 10AB X 1/2
"	BLANK	Not Available	Optional Parts Not Included
66	279818	<a href="#">W10470674</a>	Dryer Exhaust Kit

" 279969

[W10470674](#)

Dryer Exhaust Kit

" 279925

[W10470674](#)

Dryer Exhaust Kit

