


# Whirlpool LSR6334LQ1 03 - AGITATOR, BASKET AND TUB PARTS



8180203

5

Whirlpool Residential Whirlpool LSR6334LQ1 Washer Parts Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	63973	<a href="#">3362061</a>		Cap
2	<a href="#">358237</a>			Screw And Washer
3	<a href="#">358912</a>			Seal, Agitator Cap
4	<a href="#">389386</a>			Agitator
5	8528150	<a href="#">W10445870</a>		Ring-Tub
6	<a href="#">3976308</a>			Gasket, Tub Ring
7	3347674	<a href="#">285727</a>		Agitator
8	3363662	<a href="#">285748</a>		Cam-Agitator
9	<a href="#">3363661</a>			Bearing, Driven Cam
10	3366877	<a href="#">80040</a>		Dog-Agitator
11	389141	<a href="#">3360824</a>		Auger, Agitator
12	<a href="#">21366</a>			Nut, Spanner
13	8526017	<a href="#">W10389329</a>		Clothes Container, Assembly
14	8519788	<a href="#">387240</a>		Ring, Balance
15	3350389	<a href="#">285587</a>		Washer
16	<a href="#">63849</a>			Strain Relief, Power Cord

17	<a href="#">389140</a>		Tub Block, Basket Drive
18	<a href="#">383727</a>		Gasket, Centerpodt
19	3347780	<a href="#">353244</a>	Hose, Pressure Switch
24	<a href="#">3949550</a>		Washer

