


Whirlpool RES7745RQ0 02 - TOP AND CONSOLE PARTS



Whirlpool [Residential Whirlpool RES7745RQ0 Dryer Parts](#) Parts Diagram 02 - TOP AND CONSOLE PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8274261			Do-It-Yourself Repair Manuals
2	8533951	3400859		Screw, Grounding
3	694419			Mini-Buzzer
4	8274437	279960		Endcap
6	388326			Screw, 8-18 X 1.25
7	693995			Screw, Hex Head
8	8274434	279960		Endcap
9	3395683			Receptacle, Multi-Terminal
10	8558463			HAndle And Lint Screen Assembly
13	688983	487240		Screw, For Mtg. Service Capacitor
14	8536939			Clip, Knob
15	3347243			Block, Disconnect
16	8557930	8563985		Top
17	3401684			Jumper, Wire
18	3399639			Switch, Rotary Temperature

20	94614		Terminal
21	3979617		Timer, 60 Hz
23	3394427		Clip-Harness
24	3391249		Cable Tie, Push Mount
29	8533971	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
30	357213		Nut, Push-In
31	8299871	8576502	Harness, Wiring
32	8539893		Wire, Jumper
39	3398095		Switch, Push-To-Start
40	3401144		Connector
41	3397269		Connector, Timer
48	3957383		Timer Knob Assembly
49	8557460		Knob, Control
50	3936144		Do-It-Yourself Repair Manuals
53	8271418		Bracket, Control
54	8573819		Panel, Control

