


Whirlpool TGDX640PQ1 01 - TOP AND CONSOLE PARTS



11-05 Litho in U.S.A. (LT)

1

Part No. 8180984

Whirlpool [Residential Whirlpool TGDX640PQ1 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8578193		Not Available	Guide, Use & Care
"	8562589		Not Available	Instructions, Installation
"	8528187			Wiring Diagram
"	8533781		Not Available	Sheet, Cycle Feature
"	N/A		Not Available	Following May Be Purchased
"	N/A		Not Available	DO-IT-YOURSELF REPAIR MANUALS
"	677818		Not Available	Manual, Do-It- Yourself Repair (Dryer)
2	693995			Screw, Hex Head
3	3397269			Connector, Timer
4	8274437	279960		Endcap
5	3936144			Do-It-Yourself Repair Manuals
6	3395683			Receptacle, Multi-Terminal
7	8274434	279960		Endcap
8	357213			Nut, Push-In
9	8274261			Do-It-Yourself Repair Manuals

10	8558467		Screen, Lint
11	8536939		Clip, Knob
12	8533971	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
13	688983	487240	Screw, For Mtg. Service Capacitor
14	388326		Screw, 8-18 X 1.25
15	3394427		Clip-Harness
16	8557930	8563985	Top
17	688805		Clip, Spring Knob
18	94614		Terminal
19	8557462		Knob, Push-To-Start
20	8533951	3400859	Screw, Grounding
21	8299764		Timer Assembly, 60 Hz
23	8299876		Harness, Wiring
24	3403499		Connector, 2-Postion
25	3403498		Connector, 3-Position
30	3977456		Switch, Push-To-Start
31	8557456		Timer Knob Assembly
32	8271418		Bracket, Control
33	3977947		Panel, Control
34	717252		Receptacle, Terminal

