


Whirlpool WGD5000VQ1 01 - TOP AND CONSOLE PARTS



Whirlpool Residential Whirlpool WGD5000VQ1 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10150630		Not Available	LITERATURE PARTS INSTRUCTIONS, INSTALLATION
"	W10150610		Not Available	Use & Care Guide
"	W10185979			Wiring Diagram Cycle Feature
"	W10042960		Not Available	Sheet, Cycle Feature
2	8533951	3400859		Screw, Grounding
3	3394427			Clip-Harness
4	8271365	279962		Endcap
5	3397269			Connector, Timer
6	8274261			Do-It-Yourself Repair Manuals
7	3395683			Receptacle, Multi-Terminal
8	8271359	279962		Endcap
10	8557861			Screen, Lint
11	8536939			Clip, Knob
12	8533971	90767		Screw, 8A X 3/8 HeX Washer Head Tapping

13	688983	487240	Screw, For Mtg. Service Capacitor
15	693995		Screw, Hex Head
16	8557930	8563985	Top
17	8566065		Knob, Push-To-Start
21	W10185969		Timer Assembly, 60 Hz
22	3403499		Connector, 2-Postion
23	3403498		Connector, 3-Position
25	357213		Nut, Push-In
26	W10186074		Harness, Wiring
27	3977456		Switch, Push-To-Start
28	8566061		Timer Knob Assembly
"	8566061		Timer Knob Assembly
30	717252		Receptacle, Terminal
31	94614		Terminal
32	8544895		Bracket, Control
33	W10167874		Panel, Control
34	3936144		Do-It-Yourself Repair Manuals
35	388326		Screw, 8-18 X 1.25
36	3391249		Cable Tie, Push Mount
37	3401144		Connector
38	3347243		Block, Disconnect

