


Whirlpool WGD9470WW1 01 - TOP AND CONSOLE PARTS



Whirlpool Residential Whirlpool WGD9470WW1 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10244607			Use And Care Guide
"	W10258369		Not Available	TECH SHEET
"	W10255469		Not Available	INSTALLATION INSTRUCTIONS
2	3980634	W10117263		Top
"	W10249738			Toe Panel
"	W10249739			Top
3	W10111069			Harness, Main
4	W10255229			Panel, Console
"	W10255231			Panel, Console
"	W10255230			Panel, Console
5	3391018			Tie Cable
6	W10215656			Bracket, Console
7	W10112268			Clip-Harness
8	94614			Terminal
9	3936144			Do-It-Yourself Repair Manuals
10	W10117943	8303811		Badge, Assembly

11	3390647	488729	Screw
12	W10112267		Foam-Seal Control Bracket
13	W10030070	W10012480	Kit
14	3936150		Connector, 7-Circuit
15	3395683		Receptacle, Multi-Terminal
16	693995		Screw, Hex Head
17	2203186		Connector, 5-Circuit
18	W10279773		User Interface
19	W10279709		User Interface,
20	W10012430		Encoder, Wheel Kit.
21	W10012440		Retainer-Snap
22	W10250089		Knob, Light Ring
23	W10012810	280230	Encoder, Wheel Kit.
24	W10012480		Kit
25	W10242906		Harness, Communication
26	W10012820	280230	Encoder, Wheel Kit.
27	W10190685		Knob, Control
28	W10012460	280230	Encoder, Wheel Kit.

