Maytag MDG16CSAKA 01 - CONTROL PANEL



Maytag Commercial Maytag MDG16CSAKA Dryer Parts Parts Diagram 01 - CONTROL PANEL
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	PANEL, CONTROL
002	215506			Screw, Control Panel Overlay
003	215506			Screw, Control Panel Overlay
004	22002330	22002889		Console
"	22002889			Console
"	22003088			Console
005	212276	W10116760		Screw
006	211252			Screw, Ground Wire
007	205810			Wire, Ground
008	33002432			Bracket, Back
"	33002521			Bracket, Back
"	NLA		Not Available	BRACKET, BACK (ALM)
009	306938			Knob, Selector Switch
010	33002276			Switch, Cycle Selector
011	Y313588	488234		Screw 8-32 X 1/4
012	33002243			Wire Harness, Main

013	306940	W10149462		Switch, Push-To-Start
014	Y312706	422617		Nut
015	312751			Lockwasher, Start Switch
016	Y312702			Knurled Nut, Start Switch
017	204075		Not Available	PILOT LAMP (DG MODELS ONLY)
018	215564			Lens, Indicator Light
019	16009021			Manual, Service-No Refund

the laundry company®
the laundry company®
the laundry company®