Crosley CW20P8WSC 06 - CONTROL PANEL (REV. A-E)(CW20P8xSC)



Crosley Residential Crosley CW20P8WSC Washer Parts Parts Diagram 06 - CONTROL PANEL (REV. A-E)(CW20P8xSC)
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	25-7702			Speedclip, End Cap To Control Panel
"	25-7793			Screw
"	35-2989		Not Available	CONTROL PANEL
2	35-2487	21001451		Cap- End
"	35-2488	21001452		Cap- End
3	25-7851			Speedclip, End Cap To Top
"	25-7697	25-2219		Screw
"	34-9487		Not Available	PLATE, REINFORCEMENT
4	25-7435	33002917		Screw, No.10-16
"	25-7852			Speedclip, Rr Shld To End Cap
5	53-0277		Not Available	TRIM, END CAP (RT)
"	53-0278		Not Available	TRIM, END CAP (LT)
6	25-7760			Screw
7	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping

8	25-7702			Speedclip, End Cap To Control Panel
9	53-1677		Not Available	CONTROL SHIELD
10	25-3457			Screw, Sems
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	25-7853	25-7933		Ring, Retaining
"	35-2688	21001460		Shield, Rear
11	35-2845			Timer
12	25-0088	489483		Screw 10-32 X 1/2
13	35-0180	12500058		Knob Ski
14	35-0498	12500058		Knob Ski
15	35-2838	35-2839		Switch
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
16	35-0145	21001283		Knob, Selector----Piq
17	35-2619		Not Available	SWITCH 4POS SPEED
"	35-2801	21001554		Switch, Water Level
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	35-3283	21001554		Switch, Water Level
NI	35-2990-1		Not Available	MANUAL, USE & CARE

the laundry company®
the laundry company®