Magic Chef W26HY2K 04 - CONTROL PANEL (W26HN2K)(REV. E)

SECTION: BACKGUARD
MODEL: W26HN-2K



Issue Date: 6/90

Magic Chef Residential Magic Chef W26HY2K Washer Parts Parts Diagram 04 - CONTROL PANEL (W26HN2K)(REV. E)
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	25-7702			Speedclip, End Cap To Control Panel
"	25-7793			Screw
"	35-2169		Not Available	CONTROL PANEL
2	35-2488	21001452		Cap- End
"	35-2487	21001451		Cap- End
3	34-9487		Not Available	PLATE, REINFORCEMENT
"	25-7697	25-2219		Screw
"	25-7851			Speedclip, End Cap To Top
4	25-7435	33002917		Screw, No.10-16
"	25-7852			Speedclip, Rr Shld To End Cap
5	53-0277		Not Available	TRIM, END CAP (RT)
"	53-0278		Not Available	TRIM, END CAP (LT)
6	25-7760			Screw
7	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping

8	25-7702			Speedclip, End Cap To Control Panel
9	53-1676			Shield, Control
"	35-2688	21001460		Shield, Rear
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	25-3457			Screw, Sems
11	35-2325	35-2789		Timer
12	25-0088	489483		Screw 10-32 X 1/2
13	35-2254	12500058		Knob Ski
14	35-2486	12500058		Knob Ski
15	35-0119			Rotary Switch
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
16	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	35-2185	21001283		Knob, Selector----Piq
17	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	35-2145	21001554		Switch, Water Level
"	35-2457		Not Available	MANUAL, U&C INSERT

the laundry company®

the laundry company®