


Dexter DCTD30 Burner Housing Group



Dexter Commercial Dexter DCTD30 Dryer Parts Parts Diagram Burner Housing Group
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	9803-163-002			Housing Assy, Burner
*	9545-008-024			Screw HX Head Tapping (Mounts bracket housing to dryer)
2	9048-018-001			Burner, Main
*	9545-008-008			Screw, Burner to Support
3	9875-002-003			Electrode Assy, Ignition
*	9985-161-001			Bracket, Electrode Mtg
"	9545-008-024			Screw HX Head Tapping (Mounts bracket housing to dryer)
4	9857-134-001			Control Assy, Gas
5	9381-009-001			Manifold, Assy
*	9425-069-002			Orifice, Burner-Natural #30

"	9425-069-003		Orifice, Burner-LP #48
6	9576-203-002		Thermostat, Hi-Limit
*	9538-142-001		Spacer, Hi-Limit
"	9545-045-007	9545-010-001	Screw, Cross Recessed
7	9074-234-001		Cover, Hi-Limit Stat
*	9545-008-024		Screw HX Head Tapping (Mounts bracket housing to dryer)
8	9857-116-003		Control, Ignition Fenwall (3 trybox)
*	9545-044-002		Screw, Control Mtg
"	8640-411-003		Nut, Switch Locking
9	9897-026-001		Terminal Block
*	9545-031-004		Screw
"	9039-915-001		Bracket
"	9545-008-003		Screw, Gas Valve Mtg Bracket
10	9631-403-001		Wire Ass'y, High Voltage
11	9627-650-001		Harness Assembly, Low Voltage
12	9054-045-001		Fuseholder
13	8636-018-001		Fuse - 1.5 A.
*	8711-007-001		Transformer, Control
"	9545-012-009		Screw , Hx #10-32x1/2
"	9732-102-003		Kit, LP Conversion
"	9548-256-001		Support, Front
"	9545-008-008		Screw, Burner to Support
14	9379-164-001	9379-196-001	Valve-Gas Shutoff,
*	9458-020-003		Pipe, Gas Line
"	9918-002-002	Not Available	Boot Assy, Recirculation
"	9545-008-024		Screw HX Head Tapping (Mounts bracket housing to dryer)
"	9576-207-006		Thermostat, Safety
"	9545-045-008		Screw, Safety Stat Mtg
16	9825-057-002		Cover, Safety Stat
*	9545-008-024		Screw HX Head Tapping (Mounts bracket housing to dryer)

the laundry company[®]