

Dexter DDBD50 (Spring 2011) Integrated EasyCard Machine

the laundry company[®]

No Parts Drawing



the laundry company[®]

Dexter Commercial Dexter DDBD50 (Spring 2011) Dryer Parts Parts Diagram Integrated EasyCard Machine
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
"	9989-517-009			Panel Assy, Front Lower EC (SS)
"	9989-517-011		Not Available	Panel Assy, Front Lower EC (Wht)
"	9989-517-012		Not Available	Panel Assy, Front Lower EC (Alm)
"	9506-450-001		Not Available	Wiring-Schematic
"	9506-451-001		Not Available	Wiring-Diagram
"	9627-731-001			HARNESS-KIT,DEXTER
"	9806-013-003			CABLEASY- 4TWISTPR,20'SHLD/UNSH
"	9797-009-001			Card Reader Assy Complete (Includes all Below)
"	9797-006-003			CARDREADERASY- DEXTER,STANDARD

"	8502-729-001		Label-Reader
"	9982-336-001		Plate Assy, Reader mounting (No label)
"	9083-118-001		Clip Retainer
"	9209-088-001		Gromet-Lite pipe
"	9351-099-001		Lense-LED, Lite Pipe
"	9486-156-001	Not Available	Retainer-Card Reader Assy
"	8640-424-002		Nut

the laundry company[®]

the laundry company[®]

the laundry company[®]