





Dexter DLC30 Control Housing Group (Rotary Meter and Manual Timer)



Dexter [Commercial Dexter DLC30 Dryer Parts](#) Parts Diagram Control Housing Group (Rotary Meter and Manual Timer)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	9539-460-001			Switch, Push to Start
2	8502-641-002			Label, Control Instruction/Warning
3	9451-146-005			Pin, Hinge (timer plate)
4	9576-206-001	9576-209-003		Thermostat, Cont.
5	9209-037-002			Grommet, 3/16 ID
*	9029-063-001		Not Available	Bracke,t
"	9083-113-001			Clip, Temp Sensor Wires
"	9545-044-004			Screw, Thermostat Mtg
"	9545-045-001			Screw, Electrode Mtg
6	9348-056-003			Lever, thermostat
7	9307-162-001			Knob, Thermostat

*	9545-010-008	Screw, Thermostat Knob
8	9897-026-001	Terminal Block
*	9545-031-004	Screw
"	9053-067-001	Bushing, Door Switch Wires

the laundry company[®]

the laundry company[®]

the laundry company[®]