



## Dexter DRC55 Burner Housing Group



43

[Dexter Commercial Dexter DRC55 Dryer Parts](#) Parts Diagram Burner Housing Group  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">9803-163-003</a>			Housing Assembly, Burner
*	<a href="#">9545-008-024</a>			Screw HX Head Tapping (Mounts bracket housing to dryer)
"	<a href="#">9548-256-001</a>			Support, Front
"	<a href="#">9545-045-001</a>			Screw, Electrode Mtg
2	<a href="#">9048-018-001</a>			Burner, Main
*	<a href="#">9545-045-001</a>			Screw, Electrode Mtg
3	9875-002-002	<a href="#">9875-002-003</a>		Electrode Assy, Ignition
4	<a href="#">9985-161-001</a>			Bracket, Electrode Mtg
*	<a href="#">9545-045-001</a>			Screw, Electrode Mtg
5	9379-164-001	<a href="#">9379-196-001</a>		Valve-Gas Shutoff,
*	<a href="#">9458-020-003</a>			Pipe, Gas Line

6	<a href="#">9857-134-001</a>		Control Assy, Gas
7	<a href="#">9381-009-001</a>		Manifold, Assy
*	<a href="#">9425-069-015</a>		Orifice, Burner-Natural
"	<a href="#">9732-102-005</a>		KIT for coversion to use LP gas
8	<a href="#">9576-203-002</a>		Thermostat, Hi-Limit
*	<a href="#">9538-142-001</a>		Spacer, Hi-Limit
"	9545-045-007	<a href="#">9545-010-001</a>	Screw, Cross Recessed
9	<a href="#">9074-234-001</a>		Cover, Hi-Limit Stat
*	<a href="#">9545-008-024</a>		Screw HX Head Tapping (Mounts bracket housing to dryer)
10	9857-116-002	Not Available	Control, Ignition
*	<a href="#">9545-044-002</a>		Screw, Control Mtg
"	<a href="#">8640-411-003</a>		Nut, Switch Locking
11	<a href="#">9897-026-001</a>		Terminal Block
*	<a href="#">9545-031-004</a>		Screw
12	<a href="#">9631-403-001</a>		Wire AssÖy, High Voltage
*	<a href="#">9627-711-001</a>		Harness, Low Voltage Ignition
13	<a href="#">9054-045-001</a>		Fuseholder
14	<a href="#">8636-018-001</a>		Fuse - 1.5 A.
15	<a href="#">8711-002-001</a>		Transformer, Ignition Control
*	<a href="#">9545-008-026</a>		Screw, Vault Mtg