



## Dexter DRC55 Door Switch Group



41

[Dexter Commercial Dexter DRC55 Dryer Parts](#) Parts Diagram Door Switch Group  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">9041-076-001</a>			Box, Door Switch (Lower)
2	<a href="#">9550-159-001</a>			Shield, Door Switch
3	<a href="#">9539-461-001</a>			Switch, Door
4	<a href="#">8640-401-001</a>			Nut, Special Twin
5	<a href="#">9545-020-001</a>			Screw, Switch Mtg
6	<a href="#">9074-255-001</a>			Cover, Switch Box
7	<a href="#">9545-008-020</a>			Screw
8	<a href="#">9008-004-001</a>			Actuator, Switch- Lower
9	<a href="#">6068-041-001</a>			Conduit, Lower Panel
10	<a href="#">9545-012-003</a>			Screw
*	<a href="#">8641-436-000</a>			Washer, Fiber

**U.S. WASHERS**  
*the laundry company*<sup>®</sup>

**U.S. WASHERS**  
*the laundry company*<sup>®</sup>

**U.S. WASHERS**  
*the laundry company*<sup>®</sup>