


Dexter SWD Door Lock Assembly



Dexter [Commercial Dexter SWD Stacked Washer and Dryer Parts](#) Parts Diagram Door Lock Assembly
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
33	9885-024-001			Lock Assy, Complete (#1-22)(includes #1 thru #22)
1	9982-346-001			Plate Assy, Door Lock
2	8641-581-030			Washer, Flat
3	9008-005-001			Actuator, Latching Switch
4	9450-002-004			Pawl, Locking
5	8641-569-003			Washer, Spring
6	9487-200-004			Ring, Retaining
7	9029-163-001		Not Available	Bracket Switch
8	8640-413-002			Nut, Hinge to Door
9	9534-364-002			Spring, Actuating
10	9545-012-020			Screw, Hx. 10-32 x 1 0

11	8640-413-004	Nut, Elastic Stop
12	9534-364-001	Spring, Return
13	9451-193-001	Pin, Guide
14	9487-200-005	Ring, Retaining
15	8641-581-031	Washer
16	9539-461-008	Switch, Latching Sensing
17	9550-169-003	Shield, Switch
18	9545-020-001	Screw, Switch Mtg
"	8640-401-001	Nut, Special Twin
19	9539-461-007	Switch-Micro
20	9008-006-003	Actuator, Switch Locking
21	9545-020-003	Screw 4-40 x 1 1/8"
"	8640-401-001	Nut, Special Twin
*	9552-037-001	Shim, Door Lock, Thin
"	9545-018-014	Screw, Lock mtg 1/4"-20 x 3/4"
"	8641-582-007	Lockwasher 1/4"

the laundry company[®]

the laundry company[®]