


Dexter SWD Dryer Cabinet Group



Dexter Commercial Dexter SWD Stacked Washer and Dryer Parts Parts Diagram Dryer Cabinet Group
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	9960-256-030	9960-256-030P		Door assy.
"	9960-256-037			Loading Door Complete SS/Chrome/Blk
2	9960-255-008			Door Assy, Loading-SS(ring only)
"	9960-255-016			Door Assy, Loading-Chrome(ring only)
3	9982-280-011			Plate Assy, Hinge (SS)
4	9545-012-015			Screw, Hinge to Door
*	8640-413-002			Nut, Hinge to Door
5	9212-002-003			Glass, Door
6	9206-164-009			Gasket, Glass
"	9206-413-001			Gasket, Glass, Black

*	9548-117-000		Support, Door Glass
7	9206-420-002		Gasket, Outer Rim
"	9206-420-003		Gasket, Door Outer Rim (Black)
8	9244-082-001		Handle, Loading Door
*	9545-018-017		Screw, Handle 1/4-20 x 3/8
"	9531-033-001		Stud, Door Catch
"	8640-413-001		Nut, Hex
"	8640-413-003		Nut
"	9086-015-002		Catch, Loading Door
9	9544-047-007	9544-047-007P	Hinge strap-gray
"	9544-047-011		Strap, Hinge (Chrome/Black)
10	9545-052-001		Screw, Door to Hinge Strap (Special Black Type)
11	8641-436-003		Washer, Fiber
12	9989-465-001		Front Pannel Assy
*	9277-053-001		Insulation-Front Panel-Top Half
"	9277-053-002		Insulation-Front Panel-Lower Half
13	9412-102-001		Name Plate-Dryer, SWD
14	9141-154-001		Escutcheon-Dryer Coin
*	9545-031-009		Screw-TRHD Torx, 6BSDx1/2,BLK
15	9435-009-001		Overlay-Escutcheon, Coin WSD
16	8650-012-003		Lock and Key, Control
*	6292-006-007		Key
"	9095-041-001		Cam, Lock
"	8641-581-010		Washer, Spacer- Thin
"	8641-581-041		Washer-Flat