


Dexter SWD Electrical Box / Ignition Control



Dexter [Commercial Dexter SWD Stacked Washer and Dryer Parts](#) Parts Diagram Electrical Box / Ignition Control
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	9857-128-001			Control Assembly-Ignition, Complete (2-9 included)
2	9807-079-001			Box- Ignition Control
3	9857-116-003			Control, Ignition Fenwall (3 trybox)
4	9897-026-001			Terminal Block
5	8711-011-001			Transformer Ignition
6	9631-403-002			Wire, Hi Voltage
7	9627-678-001			Harness, Low Voltage Ignition
*	8220-001-225			Wire Assy, RED 9" Transformer to Fuse Holder
8	9029-048-001		Not Available	Bracket Fuse Holder
9	9200-001-002			Fuseholder

* [8636-018-001](#)

Fuse - 1.5 A.

" [9277-041-013](#)

Insulation, Electrical Box (back)

laundries
the laundry company[®]

laundries
the laundry company[®]

laundries
the laundry company[®]