


Dexter WCAD18KCS-12 (T-300) Chassis and Drain



Dexter [Commercial Dexter WCAD18KCS-12 \(T-300\) Washer Parts](#) Parts Diagram Chassis and Drain
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	9945-093-002			Base Assy,Frame
2	9930-135-001			Outer Tub Assy
--	9869-006-001			Tub and Cylinder Assy.
4	9950-045-002			Ring Assy, Tub Mtg-Front
7	9950-046-002			Ring Assy,Clamp Tub Mtg.- Rear
8	9545-017-009			Screw, Hx Cap
--	9545-030-002			Screw Tube (Bracket to Base 1/4Bx3/4)
11	9915-116-004			Tube Assy, Drain
--	8641-582-016			Lockwasher
"	8640-417-005			Nut, 1/2 - 13
"	9242-455-001	9242-468-001		Hose Tub to Drain Valve

9	9379-177-009		Valve, Drain (includes #2 thru #11)
10	9029-005-001		Bracket, Drain Valve
--	9545-008-026		Screw, Vault Mtg
19	9242-451-002		Hose, Drain Valve to Tube
--	8654-117-014		Clamp, Hose to Vacuum Breaker
"	9552-038-003	Not Available	Shim, Support Assembly (thin)
18	9242-458-002		Hose, Vacuum Brkr. to Tub
13	9122-105-004	Not Available	Dispenser Soap
15	9206-416-001		Gasket, Dispenser
--	8640-399-007		Nut Spring SS
"	9242-450-002		Hose, Dispenser to Tub
"	8654-117-008		Clamp, Hose Vent
14	9732-137-001		Back Assy, Tub 2 piece
16	9545-029-003		Bolt, 3/8-16 x 1 1/2
17	8640-415-004		Nut

