




Dexter WCAD20KCS-10 (T300) Chassis And Drain Parts



Dexter [Commercial Dexter WCAD20KCS-10 \(T300\) Washer Parts](#) Parts Diagram Chassis And Drain Parts
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	9945-093-002			Base Assy,Frame
2	9930-135-001			Outer Tub Assy
*	9869-006-001			Tub and Cylinder Assy.
"	9950-045-002			Ring Assy, Tub Mtg-Front
7	9950-046-002			Ring Assy.Clamp Tub Mtg.- Rear
8	9545-017-009			Screw, Hx Cap
*	8641-581-018			Washer
25	9242-468-001			Hose Tub to Drain Valve
26	8654-117-014			Clamp, Hose to Vacuum Breaker
9	9379-177-010			Valve, Drain
19	9242-451-002			Hose, Drain Valve to Tube

"	8654-117-014		Clamp, Hose to Vacuum Breaker
10	9029-005-001		Bracket, Drain Valve
*	9545-008-026		Screw, Vault Mtg
11	9915-116-004		Tube Assy, Drain
*	9545-030-002		Screw Tube (Bracket to Base 1/4Bx3/4)
12	9942-449-002	Not Available	Hose, Overflow to drain
*	9552-038-003	Not Available	Shim, Support Assembly (thin)
18	9242-458-002		Hose, Vacuum Brkr. to Tub
13	9122-005-004		Dispenser Soap
15	9206-416-001		Gasket, Dispenser
*	8640-399-007		Nut Spring SS
"	9242-450-002		Hose, Dispenser to Tub
"	8654-117-008		Clamp, Hose Vent
14	9732-137-001		Back Assy, Tub 2 piece
16	9545-029-003		Bolt, 3/8-16 x 1 1/2
17	8640-415-004		Nut
	9242-175-000		Hose, Pressure Switch
"	8654-117-015		Clamp, Pressure Switch Hose