


Dexter WCAD20KCS-10 (T300) Gear Motor Door Lock Assembly



Dexter [Commercial Dexter WCAD20KCS-10 \(T300\) Washer Parts](#) Parts Diagram Gear Motor Door Lock Assembly
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
*	9892-014-001			Actuator Assembly (Includes 1-10, Rod NOT included)
11	9545-012-027			Screw Pnhdcr, 10-32 UNFx0 .75
10	9545-031-011			Screw #6 x 5/16"
9	9545-044-003			Screw -Hxwshrhdslsems, 6-32 x 3/16
8	9914-137-011			Motor & Gear Train (complete)
7	9534-350-001			Spring - Extension
6	9586-001-001			Thermoactuator 120 V
5	9001-063-001			Arm - Door Lock
4	9538-157-021		Not Available	Spacer, Plastic
3	9029-204-001		Not Available	Bracket Slide Lock

2	9985-189-001	Not Available	Bracket Assy, Slide - Unlock
1	9985-190-001	Not Available	Bracket Assy, Slide Lock Actuator
*	9497-225-011		Rod, Door Lock

Woods
the laundry company®

Woods
the laundry company®

Woods
the laundry company®