


Dexter WCAD20KCS-10 (T300) Loading Door Hinge



Dexter [Commercial Dexter WCAD20KCS-10 \(T300\) Washer Parts](#) Parts Diagram Loading Door Hinge
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	9955-029-002			Door Hinge Assembly Mounts to Tub Front
2	9781-001-001			Loading Door Hinge Pin
3	9079-122-003			Loading Door Hinge Clamp (No Hinge Switch Pin) (NEW Style)
4	9487-272-001		Not Available	Masking Ring Assembly (For Newer Plunger Switch)
5	8220-063-025			Wire Assembly Door Close Switch, Red 17"
9	8220-063-026			Wire Assembly Door Close Switch, BLK 17"
10	9539-492-001			Switch, Door closed Switch (Push Button style)
11	9487-272-001		Not Available	Masking Ring Assembly (For

WWS
the laundry company[®]

WWS
the laundry company[®]

WWS
the laundry company[®]