


## Dexter WCAD20KCS-10 (T300) Transformers And Coin Handling



Dexter [Commercial Dexter WCAD20KCS-10 \(T300\) Washer Parts](#) Parts Diagram Transformers And Coin Handling  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
*	<a href="#">8220-001-235</a>			Wire Assembly - Orange/White
"	<a href="#">8220-001-338</a>			Wire Assembly-6" BLU, Transformer to Terminal Block
"	8502-730-001		Not Available	LABEL-WARNING,ELECCOINACCEPTOR
"	<a href="#">8641-582-005</a>			Lock washer, Circuit Board
1	<a href="#">8711-015-001</a>			Transformer, 120/24VAC
2	<a href="#">8711-004-002</a>			Transformer, Control (21 models)
3	<a href="#">8711-009-002</a>			Transformer, Secondary (21 models)
4	<a href="#">9021-011-001</a>			Coin Acceptor - Elec- tronic (59 models)
5	<a href="#">9119-031-001</a>			Coin Chute Assy.

*	9506-405-001	Not Available	Wiringlabel-Schematic (21 models)
"	9506-406-001	Not Available	Wiringlabel-Diagram (21 models)
"	<a href="#">9545-008-001</a>		Screw 10-32 x 1/4
"	<a href="#">9545-045-001</a>		Screw, Electrode Mtg
6	<a href="#">9627-845-001</a>		Harness for Electronic Coin Acceptor
*	9857-150-007	Not Available	Controlsassembly -Trough (21 models)

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>